

- Before first use, please check carefully for any possible damage caused in transportation.
- Before any maintenance, please confirm the power is off.
- Please do not disconnect or install the panel by non-professional individuals.
- Avoid falling or placing heavy objects on the panel.
- Please do not let the panel be exposed to rain or moisture, to avoid circuit problem.
- Please do not use the panel with overloaded voltage and/or current.
- Keep the panel out of the reach of children





# Mini LED Panel EX80

# **User Manual**



Thanks for purchasing EverSirius product. For optimal performance and safety, please read these instructions carefully before operating the product. Please keep this manual for future reference.

### **№** OVERVIEW

EverSirius powerful Mini LED panel EX80 is popular for its excellent appearance and performance. It includes DMX XLR 5pins in/out. Both CRI and TLCI are 95+. EX80 is the winner of NRK(Norwegian national broadcaster)' RFQ in 2019, due to its compact size, high light output, exact color, high-grade quality and DMX512 control. Perfect assistant for studios, broadcasting, and field shooting.

## ■ SPECIFICATIONS

Model	EX80
Power	80W
CRI	Ra 95-98
TLCI	> 95
ССТ	Bi-Color 3200K-5600K
Light source	450 pcs DIP LED
Dimmer	0~100% step-less dimming
Beam angle	60°
Working voltage	AC 100-240V, 50-60Hz / DC 12-17V
Dimension	41.9 x 43.8 x 7.7 cm (with barndoor)
Weight	3.14 kg
Working Temperature	-20℃~+45℃

#### **₩** WHAT ARE INCLUDED

- 1. LED Panel EX80 ×1
- 2. DMX XLR 5pins cable ×1
- 3. AC adapter ×1
- 4. Power cable ×1
- 5. Barn doors ×1 set
- 6. Diffusion panel ×1
- 7. Safety cable ×1
- 8. Soft bag ×1

### **№** INSTRUCTIONS

A brief introduction to facilitate your operation.



- ① V-mount battery plate. For the use of AC adapter and the battery.
- 2 Power switch.
- ③ Power cable socket.
- **4 LCD Display**. When power is on, it shows the current brightness, color temperature, and DMX channel.
  - **⑤ Dimmer**. Rotate the knob for dimming.
  - **⑥** Color temperature adjustment. Rotate the knob to adjust CCT.
  - ⑦ DMX connecting socket (out).
  - 8 DMX connecting socket (in).